

Models
MX-354 & MX-356
Programmable Synchronous
Interface
Technical Manual

Document Number: 600-247-01

Revision: A

Date: 03/03/86

Serial No.:

NOTICE

ZETACO, Inc has prepared this Technical Manual for use by ZETACO personnel and its customers to assist in the installation, operation and maintenance of the Models MX-354 and MX-356 Programmable Synchronous Interface. The information contained herein is the property of ZETACO, Inc. and shall not be reproduced in whole nor in part without prior written approval of ZETACO, Inc.

ZETACO, Inc. makes every effort to produce quality products and documentation, however, the reader must be cautioned that changes may be made to the product not reflected in the supplied documentation. If you find errors or omissions, please notify ZETACO, Inc. to remedy the problem. ZETACO, Inc. shall not be responsible for any damages (including consequential) caused by reliance on this material as presented.

If installation problems arise after you thoroughly review the manual, please contact the ZETACO Customer Support Hotline at (612) 941-9480.

Copyright 1986. All rights reserved.

REVISION HISTORY

ECO No.	Date	Description	Pages
0028	6/1/82	Per ECO	1-1
0046	8/23/82	Per ECO	6-1
0328	6/28/84	New ZETACO Cover	
0523	3/3/86	New Cover	

CUSTOMER SUPPORT HOTLINE

ZETACO, Inc. provides a Customer Support Hotline (612-941-9480) to answer technical questions and to assist with installation and trouble-shooting problems. The Hotline is manned by a technical team from 8:00 a.m. to 5:00 p.m. (Central Time) Monday through Friday.

WARRANTY INFORMATION

All ZETACO products are warranted free from manufacturing and material defects, when used in a normal and proper manner, for a period of up to two years from date of shipment. Except for the express warranties stated above, ZETACO disclaims all warranties including all implied warranties of merchantability and fitness. The stated express warranties are in lieu of all obligations of liabilities on the part of ZETACO for damages, including but not limited to, special, indirect or consequential arising out of or in connection with the use or performance of ZETACO's products.

PRODUCT RETURN AUTHORIZATION

All possible effort to test a suspected malfunctioning controller should be made before returning the controller to ZETACO for repair. However, if controller or module malfunction has been confirmed, you should return the part to ZETACO. If the part is no longer under warranty, or if the problem is not warranted, then repair will be on a time-and-material basis. A Return Material Authorization (RMA) number is required before shipment and should be referenced on all packaging and correspondence.

To ensure prompt response, the information outlined in the Material Return Information form on the following page should be gathered before calling the ZETACO Hotline for the RMA number. Please include a completed copy of the Material Return Information form with the product. Each product to be returned requires a separate RMA number and Material Return Information form.

To safeguard the product during shipment, please use packaging that is adequate to protect it from damage. Mark the box "Delicate Instrument" and indicate the RMA number(s) on the shipping label.

MATERIAL RETURN INFORMATION

All possible effort to test a suspected malfunctioning controller should be made before returning the controller to ZETACO, Inc. for repair. The speed and accuracy of a product's repair is often dependent upon a complete understanding of the user's checkout test results, problem characteristics, and the user system configuration. Use the form below to record the results of your trouble-shooting procedures. If more space is needed, use additional sheets.

TEST	RESULT
PSI DIAG	_____
UMUX REL I	_____
(or 4200)	

Other tests performed:

Please allow our service department to do the best job possible by answering the following questions thoroughly and returning this information with the malfunctioning board.

1. Does the problem appear to be intermittent or heat sensitive? (If yes, explain.)
2. Under what operating system are you running? (AOS, AOS/VS, RDOS, etc.)
3. Describe the system configuration (i.e.; peripherals, controllers, model of computer, etc.)
4. Has the unit been returned before? Same problem?

To be filled out by CUSTOMER:

Model #: _____
Serial #: _____
RMA #: _____ (Call ZETACO to obtain an RMA number.)

Returned by:

Your name: _____
Firm: _____
Address: _____
Phone: _____

TABLE OF CONTENTS

Section 1	INTRODUCTION
Section 2	INSTALLATION
Section 3	CONFIGURATION
Section 4	OPERATION
Section 5	PROGRAMMING NOTES
Section 6	APPLICATION INFORMATION
Section 7	INTERFACING
Section 8	SPECIFICATIONS
Section 9	DIAGNOSTIC TESTING
Section 10	DIAGNOSTIC LISTINGS
Section 11	LOGIC DIAGRAMS
Section 12	CABLE SPECIFICATIONS

MODELS MX-354, MX-356
PROGRAMMABLE SYNCHRONOUS INTERFACE (PSI/1-2)

1.0 INTRODUCTION

The Models MX-354 and MX-356 Programmable Synchronous Interfaces are communications controllers designed to provide half or full duplex synchronous communications control for a Data General Nova* or Eclipse* based computer system.

The PSI/2 is a two-line controller and is fully compatible with the programming formats of Data General's SLM-2 (4263) and MX-356 (4345) synchronous line multiplexers.

The PSI/1 is a single line version of the PSI/2 and is compatible with Data General's SLM-1 (4264) and MX-354 (4346)

Features of the controllers include: Programmable Line Characteristics (word length, parity type, SNY Character, DLE Character), Full Modem Control, 600-38.4K Baud Internal Clock and On-Board Cyclic Redundancy Check (CRC).

The controllers may also be used in conjunction with a Data Control Unit (DCU) to provide increased system performance. Each controller occupies one slot in the CPU Chassis.

*Nova and Eclipse are registered trademarks of Data General Corporation

2.0 INSTALLATION INSTRUCTIONS

2.1 UNPACKING

Upon receiving the interface package, unpack the contents and inspect the board for visual damage. If any damage is apparent, do not attempt to install the controller but notify ZETACO, Inc. immediately.

2.2 BOARD INSTALLATION

The controller board may be installed in any general I/O, memory - I/O or I/O only slot of the Data General Nova or Eclipse mini-computer. Install the controller in the desired slot, component side up and lock into position with release levers (see Figure 2.1) CAUTION: Be sure keyways in backplane connector line-up with slots in controller board edge connector and arrows on ribbon cable plug match arrows on cable connector (see Inset - Figure 2.1).

If with the selection of the I/O slot, a vacant slot or slots exist between the controller and the board below it, the DCHP (Data Channel Priority) and the INTP (Interrupt Priority) signals must be physically jumpered on the computer backpanel to maintain priority interrupt continuity. Install one end of a wire-wrap jumper to the DCHP - OUT signal at pin 93 at the "A" connector occupied by the device below the controller. Connect the remaining end to the DCHP - IN signal at pin 94 of the "A" connector occupied by the controller, bridging the vacant slot or slots. Similarly, connect the INTP - OUT signal (pin A-95) from the lower device to the INTP - IN signal at pin A-96 of the controller. This will complete the priority interrupt continuity to the card. If vacant slots exist between the controller and the device above the controller, perform similar strapping of the DCHP and INTP signals to maintain interrupt priority.

CAUTION: Be sure no existing cabling or devices are connected to the backplane of the slot the PSI is to be installed in.




FIGURE 2.1 BOARD AND CABLE INSTALLATION

2.3 CABLES (refer to Figure 2.1)

Ribbon cables provide communication interfacing for the PSI. The cable plugs into the 26-pin header located on the front edge of the controller board.

NOTE: When plugging the connector in, be sure to line up the arrows on the connector and header to assure proper connection.

On PSI/2 boards, separate cables are used for each line. As viewed from the front edge of the board, the right-most header is used for line 0 and the left header for line 1.

The ribbon cables should then be pulled through to the back of the computer equipment cabinet. An external cable may then be connected to the 25S connector of the ribbon cable and secured using the jack screws. For PSI/2 boards, be sure the external cables are connected to the proper ribbon connectors, line 0 or line 1.

When installation is complete, the ribbon cables should be secured to the computer chassis.

2.4 COMPUTER BACKPANEL

The backpanel of the computer provides a means for interconnecting the computer, memory, console and various controller boards and cabling to external peripheral equipment. The back panel is the vertical printed circuit board mounted on the left side of the computer chassis when viewed from the front.

On the side of the back panel facing into the chassis are pairs of printed circuit board female edge connectors, one pair for each slot. The contacts of these connectors protrude through the back panel to the left side of the minicomputer chassis.

When the male edge connectors of a printed circuit board are inserted into the female edge connectors of a slot, finger contacts on the male edge connectors meet contacts in the female edge connectors. Electrical connections to boards can, therefore, be made to pins on the back panel.

For each controller card slot, there are two horizontal parallel rows of 100 pins on the backpanel. The left group of pins is the A connector, and the right group (as viewed from the left side of the computer) is called the B connector. Numbering of each group of 100 pins is as indicated below (shown only for connector A).


BACK PANEL NUMBERING

A2	A1
A4	A3
A6	A5
A8	A7
A10	A9
A12	A11
A14	A13
A16	A15
A18	A17
A20	A19
A22	A21
A24	A23
A26	A25
A28	A27
A30	A29
A32	A31
A34	A33
A36	A35
A38	A37
A40	A39
A42	A41
A44	A43
A46	A45
A48	A47
A50	A49
A52	A51
A54	A53
A56	A55
A58	A57
A60	A59
A62	A61
A64	A63
A66	A65
A68	A67
A70	A69
A72	A71
A74	A73
A76	A75
A78	A77
A80	A79
A82	A81
A84	A83
A86	A85
A88	A87
A90	A89
A92	A91
A94	A93
A96	A95
A98	A97
A100	A99

3.0 CONFIGURATION

Processor selection (CPU/DCU), device codes, line address, local clock speed, and +12 Volt power source are selectable and should be checked and configured per system requirements before installation. To do this, the board cover must be removed.

Switch functions are indicated near the switches. Each switch consists of eight individual switches numbered 1-8 (see below). Jumpers are also used and are "IN" if the foil is not cut or a wire is in its place. Jumpers are "OUT" if the foil is cut or wire removed. Use 24 gauge solid insulated wire for jumper replacement.




Switch is shown with positions 1, 3 and 8 closed; all other positions are open.

3.1 PROCESSOR (CPU/DCU) SELECTION

The PSI/1-2 may be configured to operate in one of two modes-the first is the CPU mode-in this mode, the controller board responds to commands from the CPU via the backplane. This requires the CPU to handle all communications on a character to character basis-greatly increasing processor overhead.

The second mode, or DCU mode allows a Data Control Unit to directly control the PSI. The PSI resides in the CPU chassis using only power from the backpanel. A jumper plug is used to pass signals from the DCU/50 or DCU/200 to the controller board. One or more PSIs may be daisy-chained off the DCU to provide several synchronous lines with minimal system overhead.

Units from the factory are initially set up to operate in the CPU mode. To operate using the DCU, jumper J2-3 (located near chip loc. B4) must be cut or out, and two jumper plugs must be installed on the backplane. (see below)




3.2 DEVICE CODE SELECTION

The line sections and the CRC sections of the PSI board are accessed via two separate device codes. Mnemonics are MUX and CRC. The MUX is always an even device code and CRC is always the next higher consecutive odd device code. Primary device codes for MUX and CRC are 34_8 and 35_8 , respectively, and secondary device codes are 44_8 , 45_8 . The device code select switch, however, allows the user to select any pair of consecutive device codes. Refer to the figure below to set the desired device code.

NOTE: The switches must be set to the MUX (even) device code.

DEVICE CODE SELECT SWITCH (location X-2)



SW1 = DS0
SW2 = DS1
SW3 = DS2
SW4 = DS3
SW5 = DS4
SW6 = Not Used
SW7 = Not Used
SW8 = Not Used

Open = Logic "1"
Closed = Logic "0"


SHOWN:
Device codes 34_8 (MUX) and 35_8 (CRC) selected.

3.3 LINE ADDRESS SELECTION

The methods for selecting and setting the line address of the PSI vary depending on the board type.

- For single line boards (PSI/1), any line address in the range 0-377₈ may be selected.
- For dual line boards (PSI/2), any two consecutive line addresses in the range 0-377₈ may be selected, with line 0 representing the lower, even line number, and line 1 representing the higher, odd line number. The switch must be set to the lower (even) address. (See below)

LINE ADDRESS SWITCH (Location W-4)



SW1 = Line Sel 0 (least significant)
SW2 = Line Sel 1
SW3 = Line Sel 2 Open = Logic "1"
SW4 = Line Sel 3 Closed = Logic "0"
SW5 = Line Sel 4
SW6 = Line Sel 5
SW7 = Line Sel 6
SW8 = Line Sel 7 (most significant)

NOTE 1: SW1 (Line Sel 0) is only used on single line boards. (PSI/1)


NOTE 2: On PSI/2 boards, line address must be set to lower (even) line number.

SHOWN: Line 61₈
Selected

3.4 LOCAL CLOCK SPEED SELECTION

Timing for transmitting and receiving synchronous information is usually provided to the PSI by the modem unit. However, an on-board local clock is provided on the PSI board and may be used for timing if externally clocked modems are used, or if a data link is made without modems. Baud rates are available from 600 to 38.4K baud, and are selectable using the Local Clock switch. (see below) Local clock signals are not connected internally. They must be looped back; this is usually done through the modem, but may require special cabling considerations for direct data links. (see Section 6.1.2)

LOCAL CLOCK SWITCH (location C-9)



SW1 = 38.4K Baud
SW2 = 19.2K Baud
SW3 = 9.6K Baud
SW4 = 4.8K Baud
SW5 = 2.4K Baud
SW6 = 1.2K Baud
SW7 = 600 Baud
SW8 = Not Used

NOTE: Close switch to select rate; only one switch may be closed at a time.

SHOWN:
9.6K Baud

3.5 +12 VOLT POWER SOURCE

The PSI requires +12 Volts for proper operation of the RS-232C driver chips. The source of the +12V depends on the machine being used. On older machines (Nova 1200, 2, 3 etc.), the +12V is regulated down from +15V (VINH - pin A10). In a newer machine (Nova 4, Eclipse S140), +12V is available on backplane pin B90. Jumpers J2-1 and J2-2 (located near chip loc A10) are used to select between the two sources.

- The PSI is factory set for +15V to +12V regulation, as used with a Nova 1200, 2, 3, etc. J2-2 is IN and J2-1 is OUT, or cut.
- To change the configuration for use with a +12V source, cut or remove jumper J2-2, and insert a 24 gauge wire into jumper J2-1.

4.0 OPERATION

Each line of the Programmable Synchronous Interface consists of Receiver, Transmitter, and Modem Control sections. All sections of both lines use the same device code, and each section may set the Done Flag if it is enabled and requires service.

If more than one section is requesting service at the same time, the section of highest priority will be serviced first. For each line, the receiver section has higher priority than the transmitter section, which in turn has higher priority than the modem control section. Also, for PSI/2 boards, each section of the lower number line has higher priority than the corresponding section of the higher number line. (see below)

Line 0	Receiver	-	Highest Priority
Line 1	Receiver	-	
Line 0	Transmitter	-	
Line 1	Transmitter	-	
Line 0	Modem Control	-	
Line 1	Modem Control	-	Lowest Priority

Also on the PSI controller is the CRC generator/checker, used by the receiver and transmitter sections of both lines. The CRC section uses the next higher device code than that of the other sections. The Busy Flag is active while the CRC is performing a calculation.

The PSI operates in two modes, Offline (diagnostic) and Online (normal). In Offline mode the program provides timing pulses for onboard counters and sequenced logic via I/O Pulse commands. In normal mode, timing is provided by the on-board oscillator.

4.1 DONE, BUSY AND DEVICE FLAG COMMANDS

Mnemonics for PSI programming are MUX and CRC, with MUX commands controlling receiver, transmitter, and modem control sections, and CRC commands controlling the CRC section. Start and Clear commands are meaningless unless the board is enabled. This may be done with a Set Line and Section (DOA) instruction.

Done, Busy and Device Flag commands for the MUX sections are:

- | | |
|-----------|--|
| Busy Flag | - Not used |
| Done Flag | - Active whenever an enabled line section of the board requires service. |
| F=S | - Start pulse - clears all done flags on board, puts all sections of board offline except local clock and CRC timing clock (if online), and initializes board logic. |
| F=C | - Clear pulse - clears done Flags of board and current line section, and puts all sections of board online. |
| F=P | - I/O pulse - steps internal control clock if in offline mode; has no effect in online mode. |

Done, Busy and Device Flag commands for the CRC section are:

- | | |
|-----------|--|
| Busy Flag | - Active while CRC is performing a calculation. |
| Done Flag | - Not used |
| F=S | - Start pulse - starts CRC calculation |
| F=C | - Clear pulse - clears CRC logic and partial result register. |
| F=P | - I/O pulse - steps local clock and CRC timing clock if in offline mode; has no effect in online mode. |

4.1 DONE, BUSY AND DEVICE FLAG COMMANDS (cont.)

- I/O Reset - Same as start command to MUX, however goes to all boards in chassis. (same as power on). Also puts local clock and CRC timing clock in offline mode.

4.2 INITIALIZATION AND SETUP

The PSI is initialized by an I/O Reset instruction. A start MUX command may be used if the board is first enabled with a Set Line and Section (DOA) instruction. Logic is initialized, Done Flags cleared, and the board is placed in offline mode. All receiver and transmitter sections will be turned off, modem control sections will be turned on, and transmitters will be set for non-transparent operation. Modem control output signals and line characteristics are not affected.

The Set Line and Section (DOA) instruction may then be used to select which line and section are current, or to which succeeding instructions will pertain to. This line/section remains current until set with another Set Line and Section instruction or a Read Line and Section Requesting Service (DIA) instruction.

The board may then be set up for operation by configuring each line with operating characteristics, each receiver with a SYN character, and each transmitter with SYN and DLE characters. Line characteristics must be specified prior to setting SYN and DLE characters to insure that proper parity is appended. The board is then placed online with a Clear MUX command, and the necessary line sections turned on with Control Line Section (DOC) instructions. The Modem Control and CRC sections may also require set up before operation is to begin.

4.3 RECEIVER

The receiver section of a line receives the synchronous data serially from the modem and assembles the data into characters which are then received (with parity) by the processor over the data bus. Following initialization and setup, the receiver is turned on with a Control Line Section (DOC) instruction. It then monitors the serial bit stream until it receives at least two successive SYN characters. It will then assemble the next non-SYN character and set Done. A Read Line and Section Requesting Service (DIA) instruction is executed to determine which line and section requested service. A ReadReceived Data (DIB) instruction will pass the character, right-justified onto the processor data bus. Parity is retained for CRC calculations.

Receiver errors (parity, overrun) may then be checked with a Read Receiver Status (DIC) instruction. This data, however, will only be valid if read after received data has been read from the receiver. If it is discovered that a modem section has requested service rather than the receiver, this data represents new modem status, and the data read from the receiver becomes invalid. After verification of receiver status, the program may issue a Start command to the CRC to calculate a new CRC word.

The program may change line characteristics (with the exception of word length) while the receiver is turned on.

4.4 TRANSMITTER

The transmitter section of a line handles the serialization of data to be passed to the modem. Following initialization and setup, the transmitter is turned on with a Control Line Section (DOC) instruction, after which

4.4 TRANSMITTER (cont.)

it will immediately set Done, indicating that it is ready to accept a character for transmission, and begin to underrun. The underrun consists of a series of SYN characters transmitted if the transmitter is in non-transparent mode or DLE character - SYN character pairs if transmission is in transparent mode.

Data may be transmitted via Transmit Data (DOB) instruction. When the transmitter is ready to accept another character, Done will set. A Data In-A is executed to determine which line/section requested service. The Done condition may be cleared by a NIOC or DOBC MUX instruction.

Bits 2 and 3 of the transmit data accumulator control the transmission mode, either non-transparent or transparent. If the mode of operation is changed, the transmitter will insert a DLE character before the transmitted data.

An inactive Clear to Send signal from the modem will cause transmission to cease and the output will be held in the mark state. When CTS becomes active transmission may resume. A Transmit Underrun Sequence (DOB) instruction causes the transmitter to underrun and inhibits Done from setting until another Transmit Data instruction.

4.5 MODEM CONTROL

If the board is online, the modem control section will set Done when any of the four status signals (Carrier Detect, Clear to Send, Data Set Ready and Ring Indicator) from the modem change state. The new status may be read and Done cleared with a Read Modem Status-clear (DIC-C) instruction.

4.5 MODEM CONTROL (cont.)

Modem control output signals are set up or changed with a Set Modem Control Status (DOB) instruction. Programming of the modem control section may vary depending on the modem used. The modem user's manual should provide information on the functions of the control signals.

4.6 CRC

The CRC (cyclic redundancy check) generator/checker section is used to calculate a 16-bit word which assists in the detection of errors when a block of data is transferred over the synchronous line. The CRC section is placed on-line along with the rest of the board with a Clear MUX command, however, it can only be placed offline with an I/O Reset instruction. Once on-line, it must be cleared with a Clear CRC command before being used.

Whenever processor data is read from a receiver or sent to a transmitter, it is sent to the CRC section. A start CRC command will then cause a new CRC word to be calculated. Because the CRC section is used by each receiver and transmitter section it may be necessary to use the Read CRC Partial Result (DIB) and Load CRC Partial Result (DOB) instructions each time a different section is service, in order to maintain calculations. When re-loading a partial result, the CRC section must first be cleared with an NIOC or DIBC command.

4.7 LOOPBACK


Either line may be placed in loopback mode with a Specify Line Characteristics (DOC) instruction. Loopback mode provides for the testing of each line by connecting the transmitted data path to the received data input. The local clock is used for all timing and Clear to Send is forced active.

For normal operation, loopback mode must be off.

5.0 PROGRAMMING NOTES


The PSI/1-2 controller responds to fourteen instructions which control the various functions of synchronous communications. Some instructions are used more than once, with AC Bits 0, 1 and 15 determining the specific function. All instructions apply only to the current line address once it has been established with a Data Out-A or Data In-A. Mask bit for MUX is 8. The instructions are as follows:

- 1) Set Line and Section
DOA (f) AC, MUX




5.0 PROGRAMMING NOTES (cont.)

2) Transmit Data
DOB (f) AC, MUX




5.0 PROGRAMMING NOTES (cont.)

- 3) Transmit Underrun Sequence
DOB (f) AC, MUX




- 4) Set Modem Control Status
DOB (f) AC, MUX




5.0 PROGRAMMING NOTES (cont.)

- 5) Control Line Section
DOC (f) AC, MUX




5.0 PROGRAMMING NOTES (cont.)

- 6) Set SYN Character
DOC (f) AC, MUX




5.0 PROGRAMMING NOTES (cont.)

7) Specify Line Characteristics
DOC (f) AC, MUX




5.0 PROGRAMMING NOTES (cont.)

- 8) Set DLE Character (Transmitter only)
DOC (f) AC, MUX




- 9) Read Line and Section Requesting Service
DIA (f) AC, MUX




5.0 PROGRAMMING NOTES (cont.)

- 10) Read Received Data
DIB (f) AC, MUX




- 11) Read Receiver Status
DIC (f) AC, MUX




5.0 PROGRAMMING NOTES (cont.)


- 12) Read Modem Status
DIC (f) AC, MUX



- 13) Load CRC Partial Result
DOB (f) AC, CRC



- 14) Read CRC Partial Result
DIB (f) AC, CRC



6.0 APPLICATION INFORMATION

6.1 SERIAL INTERFACE

The 25S connector on the internal cable provides serial interface for the PSI. The connector's pin assignments are standard EIA RS-232C and can be found in Section 7.3.

6.1.1 MODEM CONNECTION

Connection to synchronous modems using a 25S connector for digital interface is accomplished using a standard pin to pin cable with 25P connectors on each end (# 300-056-00, available as option). If the modem is externally clocked, be sure that the Local Clock on the PSI is set to provide the proper speed (Section 3.4).

6.1.2 DIRECT DATA LINK

Limited distance direct data links may be made between two synchronous line interfaces by using a modified cable. The signal connections for linking two PSI lines in full-duplex over a direct data link is shown in Figure 6.1 on the following page.




Figure 6.1
 Signal Connections for directly connecting
 two PSI lines

6.2 USING MULTIPLE PSI/PTI BOARDS

6.2.1 GENERAL

In systems which require more synchronous lines than are provided by the controller, or in systems in which asynchronous in addition to sync lines are needed, additional controller boards may be installed and use the same device code. However, system limitations must be considered, and inter-board priority must be established.

Although the total number of communication lines available per device code is 256, due to system limitations the number of useable lines may be less. Considerations must be taken as to the number of sync and async lines the system allows, line address requirements, and maximum allowable transfer rates before overruns occur.

Custom Systems offers a multi-line async controller that may be used with the PSI/1-2. The Model 420 Programmable Terminal Interface (PTI) provides async control of up to sixteen display terminals, serial printers, or Bell 103 modems.

6.2.2 ADDRESSING

Because all lines use the same device code, each board must be set to distinguish its lines from lines on other boards. Usually, the higher the priority of a board, the lower its line address. Sync lines should be given priority over async lines. For example, a system using one PSI/2 and two PTI controllers may have the PSI/2 set for line addresses 0-1, one PTI set to $20_8 - 37_8$, and the second PTI set to $40_8 - 57_8$.

6.2.3 INTER-BOARD PRIORITY

The boards should be placed in the chassis with highest priority board closest to the communication processor (either CPU or DCU), and the second highest priority board in the next slot, etc. Also, a Data-In-A priority scheme must be established between the board as follows:

- For systems using the CPU as communications processor, connect a jumper from backpanel Pin A83 (PRI-OUT) of the highest priority board (closest to the processor) to Pin A84 of the next lower priority board. Then connect Pin A83 of that board to Pin A84 of the next board. Repeat for all PSI and/or PTI boards in the chassis.

- For systems using a DCU as communications processor, jumpering is provided by the DCU backpanel jumper plugs. See Section 3.1 for installation and Section 12 for wiring specifications.

7.0 INTERFACING

7.1 INTERFACE SIGNALS (CPU)

<u>SIGNAL NAME</u>	<u>ACTIVE LEVEL</u>	<u>PIN NUMBERS</u>
Data 0	L	B62
Data 1	L	B65
Data 2	L	B82
Data 3	L	B73
Data 4	L	B61
Data 5	L	B57
Data 6	L	B95
Data 7	L	B55
Data 8	L	B60
Data 9	L	B63
Data 10	L	B75
Data 11	L	B58
Data 12	L	B59
Data 13	L	B64
Data 14	L	B56
Data 15	L	B66
DS0	L	A72
DS1	L	A68
DS2	L	A66
DS3	L	A46
DS4	L	A62
DS5	L	A64
DATIA	H	A44
DATIB	H	A42
DATIC	H	A54
DATOA	H	A58
DATOB	H	A56
DATOC	H	A48
START	H	A52
CLEAR	H	A50

7.1 INTERFACE SIGNALS (CPU) (cont.)

<u>SIGNAL NAME</u>	<u>ACTIVE LEVEL</u>	<u>PIN NUMBERS</u>
INTA	H	A40
IOPLS	H	A74
IORST	H	A70
MASKO	L	A38
RQENB	L	B41
INTR	L	B29
SELB	L	A82
SELD	L	A80
INTP-IN	L	A96
INTP-OUT	L	A95
DCHP-IN	L	A94
DCHP-OUT	L	A93

7.2 INTERFACE SIGNALS (DCU)

DDATA 0	L	A69
DDATA 1	L	A75
DDATA 2	L	A91
DDATA 3	L	A77
DDATA 4	L	A67
DDATA 5	L	A59
DDATA 6	L	A92
DDATA 7	L	A47
DDATA 8	L	A65
DDATA 9	L	A71
DDATA 10	L	A78
DDATA 11	L	A61
DDATA 12	L	A63
DDATA 13	L	A73
DDATA 14	L	A57
DDATA 15	L	A76

7.2 INTERFACE SIGNALS (DCU) (cont.)

<u>SIGNAL NAME</u>	<u>ACTIVE LEVEL</u>	<u>PIN NUMBER</u>
DDS0	L	B13
DDS1	L	B19
DDS2	L	B23
DDS3	L	B51
DDS4	L	B27
DDS5	L	B25
DDATIA	H	B52
DDATIB	H	B53
DDATIC	H	B38
DDATOA	H	B34
DDATOB	H	B36
DDATOC	H	B49
DSTART	H	B40
DCLEAR	H	B48
DINTA	H	B54
DIOPLS	H	B11
DIORST	H	B15
DMASKO	L	B67
DRQENB	L	A49
DINTR	L	A86
DSELB	L	A90
DSELD	L	B6
DINTP-IN	L	A87
DINTP -OUT	L	A89
COMMON SIGNALS:		
PRI-IN	H	A84
PRI-OUT	H	A83

7.3 SERIAL INTERFACE SIGNALS

(Pin numbers and names are the same for both lines)

<u>SIGNAL NAME</u>	<u>25S CONN. PIN #</u>	<u>HEADER CONN. PIN #</u>
*Protective Ground	1	1
Transmitted Data	2	3
Received Data	3	5
Request to Send	4	7
Clear to Send	5	9
Data Set Ready	6	11
Signal Ground	7	13
Carrier Detect	8	15
Test 1	11	21
Transmit Clock	15	4
Receive Clock	17	8
Test 2	18	10
Data Terminal Ready	20	14
Ring Indicator	22	18
Local Clock Out	24	22

*Boards initially have no connection to Protective Ground. To connect Protective Grand to Signal Ground, insert a jumper into J17-1, located near chip loc. A10.

8.0 SPECIFICATIONS

POWER REQUIREMENTS

Power is supplied by the chassis +5 Volt and either the +15 Volt or +12 Volt power supplies.

+5 Volt current	= 2.5A Max
+12 or +15 Volt current	= 50MA Max

SERIAL INTERFACE

Communication with the modem is in accordance with EIA Standard RS-232C signal levels.

Transmit	
Mark	-12 Volts Nominal
Space	+12 Volts Nominal
Receive	
Mark	- 3 to -25 Volts
Space	+ 3 to +25 Volts

ENVIRONMENTAL

Operating Temperature	10°C to 40°C
Operating Humidity	10% to 90% NC
Non-operating Temperature	-40°C to 55°C
Non-operating Humidity	10% to 90%

9.0 DIAGNOSTIC TESTING

A diagnostic tape (400-247-00) is provided with the PSI which contains diagnostic and reliability tests for testing the controller board. If a problem is suspected, the reliability test should be run to determine if a problem exists in the controller circuitry.

The tape is 9 track, 800 bpi (bits per inch) with a "T-BOOT" loader.

9.1 LOADING AND RUNNING TESTS

With the tape loaded on the drive and ready (at load point) initiate a program-load from the tape drive unit. A menu of the contents of the tape should be displayed. Enter the file number of the test to be run followed by a carriage-return. A description of the tests on files may be found at the end of this Section.

The tests begin by asking the operator questions pertaining to hardware configuration such as controller model, device code, line address, processor type, etc. These parameters should be verified before testing.

For PSI/1-2 boards the reliability test PMUX RELI is used. This test requires no hardware modification or test plug, however, a test plug must be used if modem control is to be tested. Test plug information is found in the listing Section which follows. Once the test is running, status is periodically displayed which shows the number of successful passes of individual tests, and the total number of errors. If an error occurs a brief description of the error is displayed. If excessive errors occur, re-check hardware configuration. If errors still exist, the diagnostic test may be run to help isolate the specific problem.

NOTE: Maximum operating speed of the reliability test may vary depending on the speed of the processor used. If excessive overruns occur, reduce the local clock speed to 4800 baud or less.

9.1 LOADING AND RUNNING TEST (cont.)

The diagnostic test PSI DIAG may be run to help isolate a problem. A test plug is required which terminates the ribbon cable when running the diagnostic test. Test plug information is found in the following Section. For dual line boards (PSI/2), the test plug is jumper connecting Line 0 to Line 1. If no errors occur, "PASS..." will be displayed. If an error occurs, the program count of the error will be displayed and the test will loop on the error. A description of the error may be found by locating the program count in the listing Section which follows.

MAG TAPE 400-247-00

- File 0 - T-BOOT loader program
- File 1 - Directory - list of files on tape
- File 2 - PSI DIAG - diagnostic program for testing the PSI. ②
- File 3 - PMUX RELI - reliability test for PSI/1 or PSI/2 type boards. ①
- File 4 - UMUX RELI - reliability test for PSI/U type boards. ①
- File 5 - The previous save files in dump format for storage on-disk.

NOTE 1: If for any reason the reliability tests cannot be loaded and run, Data General's 4200 RELI and 4243R tests may be run as alternatives for PMUX RELI and UMUX RELI, respectively.

NOTE 2: To run the PSI DIAG test, a test plug must be used to terminate the 25S connector of the ribbon cable. See the listing header in the next section for plug specifications.



Please give us your comments.

Please use this form to send us your comments regarding this Technical Manual. Your input is greatly appreciated! Problems will be promptly addressed and action taken as necessary. If you wish a written reply, please furnish your name and mailing address. Thank you.

Date_____

Name_____Title_____

Firm_____

Address_____

City/State/Zip_____

TECHNICAL MANUAL TITLE_____

DOCUMENT NUMBER_____REVISION_____

ERRORS IN MANUAL:


SUGGESTIONS FOR IMPROVING EITHER THE MANUAL OR THE PRODUCT:



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 939 HOPKINS, MN 55343

POSTAGE WILL BE PAID BY ADDRESSEE



ZETA 

6850 Shady Oak Road
Eden Prairie, MN 55344